

JBL is pleased to offer this product upgrade, which improves the performance of your PartyBox speaker.

This software upgrade, version **0.38**, fixes the following:

- **Intermittent issue where unit sometimes will not enter Charging mode at 1st plug in of the power cord.**

Important Note

This software is specially designed for use with JBL PartyBox On-The-Go with a Serial number that its first two letters start with "EA" or "ET" (Example EA0017-XXXXXX or ET0001-XXXXXX). This software is not compatible with your JBL PartyBox On-The-Go if your serial number begins with something other than EA or ET. If your serial number begins with "TL" your unit is completely up to date and does not require this update. Additionally, use with any other models or brands may cause damage to the product.

DO NOT USE THIS SOFTWARE WITH ANY OTHER PRODUCTS.

How can I tell if my PartyBox speaker needs this upgrade?

- This software upgrade has the following version name: 0.38

Depending on when your PartyBox speaker was manufactured, it may already have the latest software installed from the factory. To check if its software requires an upgrade, follow these steps:

1. Power on the PartyBox speaker.
2. Press and hold both the "Volume -" & "Bass Boost" buttons simultaneously for 4-5 seconds.
3. The unit will broadcast by voice the software version loaded on the unit.

*As an example, if the following numbers are broadcasted: **038**, this means the unit is running software version **0.38**.*

4. If the software version is 0.38 (or any number greater), your PartyBox speaker has the latest software version, and no further action is needed.
5. If the software version is lesser than 0.38, proceed and carry out the upgrade according to the instructions that follow.

System requirements:

- To perform the software upgrade, you will need a USB memory stick with at least 50Mb of available storage capacity and the AC power cord of the unit.
- To install the software upgrade, you will need to UNZIP the software ZIP file "PBG_FW_202009100_Ver38_M_159.bin" onto the main root directory of the USB

memory stick. The actual software file "PBG_FW_202009100_Ver38_M_159.bin" must be on the main root directory of your USB memory stick. We recommend that there be no other files in the main "root" directory of the USB memory stick. If the root directory does contain any existing files, we recommend that you either remove them or save them to a separate folder on the memory stick.

INSTALLATION INSTRUCTIONS

PLEASE READ THESE INSTRUCTIONS CAREFULLY BEFORE PROCEEDING.

Upgrading your PartyBox speaker is easy, but for the upgrade to work properly, it is important to carefully follow the instructions below. From the moment the update is began (Step 5 below), the entire upgrade procedure may take approximately 3 minutes, and once it begins ***you must complete the entire process in one session.*** Please allow sufficient time to complete all the steps.

Attention: Do not cut off the power while updating!

1. Unzip/extract the "PBG_FW_202009100_Ver38_M_159.bin" file from the zip file downloaded and save it onto the main root directory of a USB memory stick
2. Power Off the unit.
3. Attach the USB stick into the USB Input located on the back panel.
4. Plug the AC plug into the unit then Power On the unit and allow it to fully power up.
5. Press and hold both the "Volume +" & "Bluetooth" buttons simultaneously for 12 seconds.

Note: The update is now in progress and takes roughly 3 minutes to complete from this point on. Do not pull the AC cable out or power off the unit. Leave unit alone and allow it to complete the update. The white LED will indicate the progress of the update.



Attention: Don't Pull out USB and AC power during update

6. Once the upgrade has completed, the unit will reboot itself and all LED lighting on the top and front panel will come back and resume as normal.

Congratulations, your PartyBox speaker is now upgraded to the latest software version 0.38.